

# AQUA-TITE Green

## INSTRUCTIONS

**Thank you for choosing Aqua-Tite Green, a revolutionary eco-friendly post treatment water repellent product. Aqua-Tite Green is used to restore water repellency to weathered fabrics. To achieve the full benefits of Aqua-Tite Green, please follow the instructions below.**

1. Before applying Aqua-Tite Green, please find a well ventilated area. Make sure the fabric is laying on a clean and dry surface. Avoid prolonged breathing of vapor or skin contact. Solution is combustible so do NOT apply where there are open flames.
2. It is best to wear gloves and eye goggles when applying Aqua-Tite Green.
3. Fabric must be clean and thoroughly dry before treating. Do NOT apply on damp or wet fabric. Remove dust and dirt by brushing.
4. Aqua-Tite Green can be applied by spray, brush or roller. For best results, use the sprayer that comes with the product. The "Fine Mist" setting is best. When applied as a fine mist, the water repellent diffuses into to fabric on a molecular level.
5. Place the nozzle 20 inches to 2 feet away from the fabric to be treated and deliver a fine mist of Aqua-Tite Green. Apply evenly and thoroughly and avoid run off. Spraying less than 12" away or applying too much Aqua-Tite Green will likely cause run-off. Also, white streaks may appear. This is an indication that too much Aqua-Tite Green has been applied. Applying too much Aqua-Tite Green in one application actually degrades the performance. Also, do not allow the product to pool on the fabric.
6. It is best to cover and protect all areas not intended for treatment from over spray and run off. It is NOT recommended to apply Aqua-Tite Green while the fabric is in use covering something. This includes boats, cars, motorcycles and other items.
7. After treatment, allow the fabric to completely dry for up to 72 hours. It is best if the fabric can dry in a warm environment. If it is possible, allow the fabric to dry and cure in direct sunlight for up to 3 days. Do NOT allow the treated fabric to be exposed to moisture, dew or rain until the fabric is completely dried and cured. If Aqua-Tite Green must be applied in mild or cold weather, it is recommended that before applying Aqua-Tite Green, the fabric should be heated. This can be done by putting the fabric in a dryer or using a blow dryer or hot air dryer. After applying Aqua-Tite Green, it is recommended to again warm the fabric by using a blow dryer or hot air dryer. Do NOT use a dryer that has a flame source for heat. Warming the fabric after application is essential in curing the fabric to get the full attributes and functional benefits of this product. Perform this step in a well ventilated area.
8. Keep container tightly closed. After using, thoroughly clean the brush, roller or spray nozzle. This can be done with warm water or a 5% rubbing alcohol solution in water. When using a spray nozzle, if it is not cleaned after use, blockage might occur.
9. This product is harmful if swallowed. Keep out of reach of children. If ingested, do not induce vomiting. Call a physician immediately.
10. As always, fully read the label instructions before use. We hope this helps you get the most out of Aqua-Tite Green. Thank you for using our product.